

Track Locator Kit Instructions

P/N S1170

1. Raise Car
2. Remove 1 lower rear four link bolt and install the bolt through the track locator bracket and back into four link bracket. The bracket should be on the inside of the 4-link.
3. Remove the front lower 4-link bolt, opposite of the rear and back into 4-link bracket and tighten.
4. Center housing in between the frame rails or quarter panels.
5. Make up cross bar to correct length based on the housing being centered.

Note: Rod ends should be about 2/3 into the tubing adapter.

Note: After length is determined and bar is cut the tubing adapter should be drilled for plug weld as done on other end.

